Auto Care Products, Inc.

ProSeal™ Commercial Rolling

Steel Door Bottom Seal Instructions

1. Remove existing bottom door seal. Save all hardware, it will be used to install the new bottom door seal.

2. Using a scissors or utility knife, cut the new bottom door seal to match the length of the old seal.

3. Install new bottom door seal using the existing hardware.

Made in U.S.A.

6345 Nancy Ridge Drive, San Diego, CA 92121
(858) 625-0005 ● (800) 992-2018 ● Fax (858) 625-0010 ● Email: info@auto-care.com